



GIG
CYMRU
NHS
WALES

Bwrdd Iechyd Prifysgol
Cwm Taf Morgannwg
University Health Board

HOW TO RETUBE YOUR HEARING AID MOULD

Follow these instructions:



1.

Pull the old tubing out of the earmould. Do not throw the old tubing away as you will need it later.



2.

Cut the last 5cm (2 inches) of a pre-bent piece of tubing. Make sure you cut at a slant.



3.

You should be left with a tapered end to the tubing.



4.

This tapered end needs to be pushed into the earmould



5.

Thread the tubing through the earmould



6.

All the tapered section should have come through the other side.



7.

Pull the tube until the bend reaches the earmould.



8.

Cut the tapered tubing as close as possible to the earmould.

Any tube sticking out could rub your ear and make it sore.



9.

Take the old piece of tubing you saved and line it up with the newly threaded tube.



10.

Cut the end to the same length.



11.

Push the end of the tubing onto the plastic nozzle on your hearing aid.



12.

Make sure that it bends in the correct direction, as shown in the picture.

ALTERNATIVELY YOU CAN WATCH A SHORT VIDEO ONLINE AT:

https://c2hearonline.com/video/you_tube/retubing.mp4